

Sound LAB®

INSTRUCTION MANUAL

G017L is a disco light.

I. Technical Specifications:

Item Code:	G017L(SRL-448)
Name:	MANY MUSHROOM
Volt:	AC 230V~ 50Hz 650VA
Bulb:	120V/ max. 300W x 2 64514
Fuse:	250V/5A
Color:	RED,YELLOW,GREEN, ORANGE,PURPLE,6 DICHROIC COLORS
Weight:	4kg
Size:	L360XW270XH270 mm

II. Operational Instructions:

1. Unpack the carton to check if there is any damaged or missing parts when you receive the unit, call your local dealer if anything is found not in a normal condition.
2. Keep the lamp untouched by hand and disconnect the unit from power while Re-lamping.
3. Use a clamp to hang the unit. Please note secondary hanging point for fitting a safety wire.
4. Place the unit where there is efficient ventilation, away from any flammable objects.
5. Check that the rated power corresponds to the main supply.

III. Re-lamping:

1. Disconnect from power supply and cool down the unit before re-lamping.
2. Open the lid and replace the burnt-out lamp.

3. Restore the lid.

IV. Caution:

1. For safety the following points should be carefully read and observed.
2. Ambient temperature should not exceed 35°C.
3. Disconnect from the power supply before opening or replacement of the lamp and fuse. Please be sure the lamp is cool before replacement!
4. To avoid electrical shock, do not touch any live parts when the unit is activated.
5. The lamp shall be changed if it has become damaged or thermally deformed.
6. Never use this unit in a wet or dusty room.
7. Please be sure to use only a stable base for the fixing of the luminaire.
8. If the product is to be installed then consult an approved electrician.
9. Do not cover the lamp!
10. Danger moving parts!
11. No serviceable parts refer to qualified personnel for service.